


## **LASER EMITTER DG-CA12-240-808**



Frequent malfunction of the laser handle - there is a loss of flashes and sensations. Often it is enough to look out the window of the pen to see the problem.



Hair laser no longer working properly? A common issue is the diode stack. Scan the QR and go to [www.romshi.com](http://www.romshi.com) for solutions.

site [WWW.ROMSHI.COM](http://WWW.ROMSHI.COM)