


LASER MODULE DVS-3556AS



The main reason for the breakdown of the diode laser handle is the laser does not work, and the sensations disappear. Damage is often visible through the observation glass.



Scan here to access diode laser spare part recommendations and repair videos.