

SPARE DIODE ELEMENT FOR DIODE LASER HAIR REMOVAL HANDPIECE



Often, the diode laser handle fails: the laser does not work, and the sensations disappear. Through the observation window, the cause of the breakdown is often visible.



site WWW.ROMSHI.COM

When your laser device loses power, check the diode. Scan the QR to access www.romshi.com.