


HOW TO REMOVE AND REPLACE THE 808NM DIODE STACK



How to remove and replace the 808nm diode stack Technical help for diode lasers available on
WWW.ROMSHI.COM



Buy laser modules direct from +7(918)0110234