



HOW TO TAKE OUT AND SWAP THE 808NM DIODE STACK



How to take out and swap the 808nm diode stack Repair tutorials for hair removal lasers on
WWW.ROMSHI.COM



Direct laser repair advice at +7(918)0110234